23 Mar 2017

Cast-Max[™] 2664 UV/Visible/LED Curable Ultra-Clear Encapsulating Dome Coating

PRODUCT DESCRIPTION

Incure Cast-Max™ 2664 UV/Visible/LED curable adhesive is an ultra-clear, medium viscosity, high performance metal-glass bonder/coating material widely used in many different applications in the electronics, jewelry and optical industries. Used as a coating, it cures in seconds to form a very sleek high clarity dome. Couple with enhanced moisture and temperature resistance properties, Incure 2664 exhibits very low shrinkage and low water absorption capability. It is 100% solids, contains no volatiles and it is ideal for product requiring thermal cycling.

UNCURED PROPERTIES

Chemical Type	Urethane Acrylate, 100% Solids, No Solvents Single Component, Water-White Clear				s
Appearance					lear
Density, g/ml	1.04				@20°C
Flash Point, °C	> 93)
Viscosity, cP (rpm)	20	2,000 - 4,000		Spindle	4
Other viscosities are a viscosity range reque this product may be p Email us at: support@ local distributor for mo	ASTM	D2556			

¹ Viscosity (cP) taken at 25°C - Call to enquiry for other viscosities.

RECOMMENDED UV CURE SCHEDULE (FULL CURE)

Full Surface Cure Fixture Time between glass slides			UVA	UVB	UVC	UVV
		mJ/cm ²	150	43	5	140
Exposure Time (s)	1.0	mWcm ²	150	43	5	140
S20™ Spot (4-Pole LG	i) 0.4" Dist	mJ/cm ²	3,000	530	50	3,400
Exposure Time (s)	1.0	mWcm ²	3,000	530	50	3,400
L9000™ LED Spot @ 0.67" Dist		mJ/cm ²	14,000	210	60	510
Exposure Time (s)	5.0	mWcm ²	2,800	42	12	102
F200P™ Flood @ 3.75" Dist		mJ/cm ²	450	129	15	420
Exposure Time (s)	3.0	mWcm ²	150	43	5	140
F500 [™] Focused @ 3.0" Dist		mJ/cm ²	500	160	15	480
Exposure Time (s)	1.0	mWcm ²	500	160	15	480

Above table is for reference only. Fixture Time using F200P @100% intensity, 3.75" distance. Moderate intensity conveyor systems C9000-F100x1AC/200x1AB/400x1AC/500x1AC with lamp height set at 2.5". U8000-F300x1D conveyor lamp height set at 2.1" focal point. Please consult IncureLab™ for belt speed recomm

UV INTENSITY REFERENCE TABLE

Incure UV Curing Lamp Model	⁴ Curing Distance in inches (mm)					
ARC / LED Spot	0.5" (12.6)	1" (25.4)	1.5" (38)	2" (50.8)	2.5" (63.5)	3" (76.2)
S20™ ARC (mW/cm²) / (ø mm)	1,400 (3)	1,500 (4)	650 (6)	360 (8)	240 (10)	175 (12)
L9000™ LED (mW/cm ²) / (ø mm)	7,500 (9)	5,000 (10)	2,300 (17)	1,200 (20)	700 (25)	450 (30)
ARC / LED Flood/Focus Beam	UV Intensity (mW/cm ²)					
F200™ ARC Flood (6" x 8")	325	280	245	215	190	165
F400™ ARC Flood (4" x 4")	860	570	440	345	270	215
F500 [™] ARC Focused (3" x 5")	1,040	685	530	415	325	260
L1000-365™ LED Flood (4" x 4")	2,675	2,380	1,900	1,625	1,430	1,280
L1000-405™ LED Flood (4" x 4")	2,950	2,625	2,150	1,900	1,650	1,450

⁴ Curing Distance is defined by the tip of light-guide or base of lamp housing to the bond area. All values are nominal with ±10% variation, with LED Flood Static Uniformity at ±78% and Dynamic Uniformity at ±90%. Recommended curing distances in grey.

CURING SCHEDULE FOR THIS PRODUCT

CURED PROPERTIES

Shore Hardness, Du	Shore Hardness, Durometer		ASTM 2240		
Linear Shrinkage		1.30%	ASTM 570		
Water Absorption at 24hrs		0.20%	² ISTM D2566		
Tensile (PSI) * PC-PC / SS-SS / S-S / AL-AL * PC Substrate Failure	PC-PC / SS-SS	N.A. / 5,200*	ASTM 638		
	S-S / AL-AL	4,700* / 4,700*	ASTIVI 030		
Surface After Full Cu	Surface After Full Cure		² ISTM D189		
Elongation at Break	Elongation at Break		ASTM 638		
Thermal Range (Britt	Thermal Range (Brittleness / Degrades) °C		² ISTM D366		
Young's Modulus of E	Young's Modulus of Elasticity, MPa (PSI)		³ ASTM 638		
Average Linear CTE, ppm/°C		51	² ISTM D696		

2 ISTM - refers to Incure Standard Test Method.

Tensile (%)

ASTM 638 Young's Modulus test speed @5mm/min for rigid and semi-rigid materials, @50mm/min for non-rigid materials, unless otherwise specified.

150 🗖 At 10min 🔲 At 30min 📕 At 60min 112.5 75 37.5 0 -60 22 100 125

Temperature (°C)

SECONDARY HEAT CURE (Not Applicable)

	Continuous Oven Bake	Duration
95°C (203°F) 110°C (230°F)		120 mins
		60 mins
	125°C (257°F)	30 mins

Incure, Inc. 1 Hartford Square, Box 16 West, Suite C-3, New Britain, CT 06052, USA Tel: (860) 748 2979 support@uv-incure.com RoHS Pb HF

Incure Adhesives Manufacturing Pte Ltd 33 Ubi Avenue 3 #04-23, Vertex Tower B, Singapore 408868

Tel: (65) 6509 3670 www.uv-incure.com

If you are unable to fully cure this product for some reasons, pls email us for assistance with your curing information. Below are the curing parameters: UVB (290-320nm) = 160 mW/cm² UVA (320-400nm) = 500 mW/cm² UVC (290-220nm) = 15 mW/cm² VUV (400-700nm) = 480 mW/cm² Note: This product has been thoroughly tested to cure with F200PTM UV Flood Lamp. Intensity wavelengths (shaded) are crucial for curing this product. All measurements are made with EIT UV PowerPuck II.

SHELF-LIFE, STORAGE, USE AND HANDLING OF THIS PRODUCT

Shelf-Life of this unopened product is ONE (1) year from date of manufacture. Avoid direct exposure of bottle to visible light at all times. Containers should remained covered when not in use. Product should be stored in a dark cool place of 10°C to 28°C. Transfer of product into other packages void all warranties. Users should ensure all bonding surfaces are free of grease, mold release, or any contaminants, as bonding performance will be compromised. All tests for cured bonds should be carried out at ambient temperature. For safe handling of this product, please read Material Safety Data-sheet (MSDS) prior to use. Organic solvents, such as IPA, may be used to wipe away uncured material from surfaces

EtO and GAMMA STERILIZATION (Not Applicable for this Product)

All Incure Medical products are formulated to subject to standard sterilization methods, such as EtO and Gamma Radiation of 25 to 50 kGrays (cumulative). Enhanced moisture and thermal resistance of this product show excellent adhesion and bonding strength after one cycle of steam auto-clave test. Depending on bond design and structure of the application, users should test specific assemblies after subjecting them to the test requirements. Please consult Incure Support Team for assistance, if your devices are subjected to more than one sterilization cycles

NOTE

The data contained in this document are furnished for information only. We cannot assume responsibility for the results obtained by others over whose methods we have no control. It is the user's responsibility to determine suitability for the user's purpose of any production methods mentioned herein. INCURE will not be liable for any indirect, special, incidental or consequential loss or damage arising from this INCURE product, regardless of the legal theory asserted. INCURE recommends that each user adequately test its proposed use and application before repetitive use, using this data as a guide.

Design	bv	Incure	Lab™



